



AIR CURTAIN

INSTALLATION INSTRUCTIONS

Our air curtains are simple to install and easy to operate & maintain!

1

Before hanging, check to see what the clearance is above the window.

2

Install the two flat mounting plates to the back of the air curtain using the factory supplied fasteners.

3

Lift the air curtain and attach the keyhole slots of the mounting plates to the bolts on the frame of the window and tighten the mounting hardware.

4

When hanging from the ceiling, use threaded rods and the factory installed threaded inserts.

Threaded rods supplied by others.

5

To wire – follow the wiring diagram (found inside wiring compartment). All accessories are shipped in a red bag located inside the same box as the air curtain.



For the most effective results, your air curtain should be mounted directly above and as close as possible to the service opening on the window, without interfering with access to the mechanical compartment above the window.

All wiring should be done by a qualified electrician using copper wiring.

See air curtain data sheet for electrical specifications.

ALL QUIKSERV PRODUCTS ARE SHIPPED FULLY-ASSEMBLED AND READY TO INSTALL.